



Thank you for choosing a Supreme Legends USA product!! We believe you will find Supreme quality, fit and finish to be second to none.

Your grip set should include:

- (1) Throttle Side Grip
- (1) Clutch Side Grip



#### INSTALLATION INSTRUCTIONS:

1. Remove the stock clutch handlebar grips from the bar.
2. Remove all residue, glue, or materials from the surface of the handlebar.
3. Place the clutch side grip on your bar (grip w/ set screws) and lock set screws into place, being sure to use a light thread locking compound on the screws before securing their location.
4. Next remove the screws which hold your throttle cable housing together, being sure to capture any screws or brackets which may be attached.
5. Remove the cables from the grip, being sure to note which goes into which position on the grip. There will be two cables, one which is routed underneath the grip and the other straight into it's housing. Turn the grip a bit to gain slack in the cables and remove the cable ends.
6. Remove the stock grip off the handlebar. Next apply a good grade of waterproof grease or other viscous lubricant to the handlebar end and across the surface where the twist grip will rest.
7. Install your new throttle grip onto the bar.
8. Attach the cable ends as they were prior to removal, being certain to route the cables into the groove as necessary.
9. Replace the cable housing around the grip and secure all screws and bracket, again, being sure to use a light thread locking compound.
10. Ensure that throttle operates smoothly before riding the motorcycle.

\*\*If cables are too tight, especially while bars are in full turn of either direction, it may be necessary to adjust the cable play adjuster at the carburetor end.